

# ALFA ROMEO MiTo 1.4 MultiAir (135 HP) ALFA TCT User Manual

|                           |                                       |
|---------------------------|---------------------------------------|
| <b>Torque</b>             | 251 lb-ft @ 3600 RPM                  |
| <b>Power</b>              | 86 HP @ 3750 RPM                      |
| <b>Front/rear Track</b>   | 52.7/52.7 in                          |
| <b>Unladen Weight</b>     | 3227 lbs                              |
| <b>Gross Weight Limit</b> | 3356.7 lbs                            |
| <b>Tire Size</b>          | P205/60 HR 15                         |
| <b>Length</b>             | 186.22 in                             |
| <b>Height</b>             | 71.2 in                               |
| <b>Fuel System</b>        | Sequential multi-point fuel injection |
| <b>Combined</b>           | 47.02 mpg US                          |
| <b>Gearbox</b>            | Xtronic CVT                           |
| <b>CO2 Emissions</b>      | Tier2Bin5 (EPA)/LEV2-ULEV (CARB)      |
| <b>Displacement</b>       | 1235 cm <sup>3</sup>                  |
| <b>Rear</b>               | Vented Disc                           |
| <b>Highway</b>            | 20.4 mpg US                           |
| <b>Cd</b>                 | 0.299                                 |
| <b>Ground Clearance</b>   | 4.96 in                               |
| <b>Front</b>              | Vented Disc                           |