

# DAIHATSU Rocky Hardtop Owners Manual

|                           |  |
|---------------------------|--|
| <b>Torque</b>             | 195 Nm @ 4250 RPM                      |
| <b>Tire Size</b>          | 225/55HR16                             |
| <b>Unladen Weight</b>     | 2971.8 lbs                             |
| <b>Power</b>              | 165 HP @ 5000 RPM<br>With Start & stop |
| <b>Front/rear Track</b>   | 62.7/60.9 in                           |
| <b>Gross Weight Limit</b> | 5875 lbs                               |
| <b>Length</b>             | 162.59 in                              |
| <b>CO2 Emissions</b>      | 223.7 g/km                             |
| <b>Top Speed</b>          | 124.1 mph                              |
| <b>Cd</b>                 | 0.312                                  |
| <b>City</b>               | 34.59 mpg US                           |
| <b>Displacement</b>       | 1616 cm <sup>3</sup>                   |
| <b>Cargo Volume</b>       | 230.9 cuFT                             |