

# FIAT Brava 1.6 (90 HP) Service Manual

<b>Tire Size</b>	225/50VR16
<b>Power</b>	197 BHP @ 4900 RPM
<b>Torque</b>	145.4 lb-ft @ 4000 RPM
<b>Unladen Weight</b>	1860.7 lbs
<b>Displacement</b>	2389 cm <sup>3</sup>
<b>Cargo Volume</b>	144.4 cuFT
<b>CO2 Emissions</b>	300 g/km
<b>Highway</b>	35.8 mpg US
<b>Front/rear Track</b>	63.4/65.3 in
<b>Wheelbase</b>	109.1 in
<b>Length</b>	216 in
<b>Gross Weight Limit</b>	5533.6 lbs