

# FIAT Panda 4X4 (2003 - 2012) User Guide

<b>Power</b>	295 BHP @ 4000 RPM
<b>Torque</b>	600 Nm @ 1750-4500 RPM
<b>Front/rear Track</b>	63.8/64.3 in
<b>Gross Weight Limit</b>	5864.3 lbs
<b>Displacement</b>	5379 cm <sup>3</sup>
<b>Wheelbase</b>	126.3 in
<b>Tire Size</b>	245/55 WR17
<b>Unladen Weight</b>	4188.8 lbs
<b>Cylinders</b>	Straight-six
<b>Rear</b>	Inner Vented Discs
<b>Gearbox</b>	6-speed, Automatic
<b>CO2 Emissions</b>	327 g/km
<b>Length</b>	198 in
<b>City</b>	12.5 mpg US
<b>Front</b>	Inner Vented Discs
<b>Height</b>	58.4 in
<b>Combined</b>	15.6 mpg US
<b>Highway</b>	21.9 mpg US