

# FIAT Stilo 5 Doors (2006 - 2007) User Guide

<b>Torque</b>	323 Nm @ 5000 RPM
<b>Unladen Weight</b>	3479 lbs
<b>Acceleration 0-62 Mph (0-100 kph)</b>	8.8 s
<b>Power</b>	199 KW @ 6200 RPM
<b>Front/rear Track</b>	61.1/61 in
<b>Gross Weight Limit</b>	4024.1 lbs
<b>Fuel System</b>	Multi-Point Injection
<b>Tire Size</b>	P215/45R17
<b>Height</b>	55.3 in
<b>CO2 Emissions</b>	200 g/km
<b>Highway</b>	29 mpg US
<b>Ground Clearance</b>	4.7 in
<b>Width</b>	70.9 in
<b>Cargo Volume</b>	14.1 cuFT
<b>Cd</b>	0.27
<b>Top Speed</b>	152 mph
<b>Displacement</b>	2156 cm <sup>3</sup>
<b>City</b>	23 mpg US
<b>Cylinders</b>	L5
<b>Length</b>	191.7 in
<b>Wheelbase</b>	101.2 in
<b>Combined</b>	29.5 mpg US
<b>Gearbox</b>	Manual, 5 Speed