

# NISSAN 100 NX 1.6 4AT (90 HP) Owners Manual

|                           |                             |
|---------------------------|-----------------------------|
| <b>Torque</b>             | 663.8 lb-ft @ 2300-3000 RPM |
| <b>Displacement</b>       | 6967 cm <sup>3</sup>        |
| <b>Front/rear Track</b>   | 58.9/59.2 in                |
| <b>Power</b>              | 150 HP @ 3000 RPM           |
| <b>Unladen Weight</b>     | 2744 lbs                    |
| <b>Tire Size</b>          | 32 X 6.75                   |
| <b>Wheelbase</b>          | 144.9 in                    |
| <b>Length</b>             | 216.5 in                    |
| <b>Combined</b>           | 53.3 mpg US                 |
| <b>Gross Weight Limit</b> | 4199 lbs                    |
| <b>CO2 Emissions</b>      | 437 g/km                    |
| <b>Gearbox</b>            | 5-Speed Automatic           |
| <b>Height</b>             | 48.2 in                     |
| <b>Ground Clearance</b>   | 0.3 in                      |
| <b>Cargo Volume</b>       | 4.6 cuFT                    |