

RENAULT Megane Estate 1.6 16v 6MT (110 HP) User Manual

| | |
|---------------------------|---------------------------------------|
| Displacement | 988 cm ³ |
| Torque | 128 Nm @ 2800 RPM |
| Unladen Weight | 3430 lbs |
| Power | 600 HP @ 6800 RPM |
| Front/rear Track | 61.2/62.2 in |
| Gross Weight Limit | 4698 lbs |
| Tire Size | 155/70 R13T |
| CO2 Emissions | Tier 2 Bin 5 (Fed) |
| Front | Vented Disc |
| Height | 71.2 in |
| Length | 146.4 in |
| Width | 70.07 in |
| Rear | Vented Disc |
| Cargo Volume | 28.9 cuFT |
| Gearbox | CVT(Continuous Variable Transmission) |