

# SUBARU Liberty Sedan 3.6 5AT (260 HP) Maintenance Manual

<b>Torque</b>	300 Nm @ 2500-4000 RPM
<b>Power</b>	184 HP @ 5000 RPM System output 250kW / 340HP
<b>Tire Size</b>	205/55 R16 91 H
<b>CO2 Emissions</b>	131 g/km
<b>City</b>	41 mpg US
<b>Displacement</b>	2993 cm <sup>3</sup>
<b>Gross Weight Limit</b>	4266.7 lbs
<b>Front/rear Track</b>	59.3/60.4 in
<b>Front</b>	Vented Discs
<b>Unladen Weight</b>	3130.6 lbs
<b>Top Speed</b>	151.6 mph
<b>Height</b>	55.63 in
<b>Length</b>	178.4 in
<b>Ground Clearance</b>	5.51 in
<b>Highway</b>	55 mpg US
<b>Wheelbase</b>	110.63 in
<b>Rear</b>	Vented Discs
<b>Cd</b>	0.24