

# VOLKSWAGEN Beetle Maintenance Manual

<b>Torque</b>	129 Nm @ 4300 RPM
<b>Front</b>	11.8 in. Ventilated Discs
<b>Displacement</b>	1594 cm <sup>3</sup>
<b>Front/rear Track</b>	58.6/59 in
<b>Unladen Weight</b>	3320.1 lbs
<b>Power</b>	114 HP @ 6100 RPM
<b>Length</b>	150 in
<b>Gearbox</b>	6-speed automatic (DCT)
<b>Highway</b>	42.6 mpg US
<b>Gross Weight Limit</b>	2945.4 lbs
<b>Rear</b>	Solid Discs - 10.3"
<b>Combined</b>	33.2 mpg US
<b>Tire Size</b>	P195/65T15
<b>Height</b>	75.8 in
<b>Top Speed</b>	113.6 mph
<b>Cargo Volume</b>	25 cuFT
<b>City</b>	32.8 mpg US
<b>Wheelbase</b>	158.5 in
<b>CO2 Emissions</b>	LEV-II ULEV